Packaging (and associated) Technologies for Large Arrays

T. Gaier

Overview

- Large Array Requirements
- Accommodating New Technologies
- Packaging Technologies
 - Single function Modules: SEQUOIA, WMAP etc (N=10-50)
 - Multi-function modules: QUIET, MIMRAM, MAS (N=100-500)
 - New Approaches: Wafer level packaging (N=500-5000)

Array Receiver Requirements

Arrays are needed when:

1) Individual detector noise approaches fundamental limits InP HEMTs, SIS

2) Large areas (compared to resolution) needs to be observed continuum and spectral line surveys, CMB, Earth Science

Receiver Array Requirements:


- Large array integration must be facilitated- interconnections, integration, bias and readout
- Single pixel performance needs to be maintained- beam integrity, noise performance etc
- New Technologies need to be accommodated- Incremental improvements need to be accounted for

The parts have to be testable or highly repeatable


Evolution of Technology

- Evolution has been substantial for high frequency (>100 GHz) devices
 - 1998 Room temp NF =3dB @90 GHz, 6 dB @180 GHz
 - 2010 Room temp NF=2.5 dB @90 GHz, 3 dB @180 GHz


Recent G-Band Results



90 GHz 35 nm results




Wafer Probe Noise Measurement-40 GHz



New High Frequency Breakthroughs

•In a Spontaneous Concept RTD from 2007, we designed MMICs in the 400-500 GHz range. At the time, there was no way to test them because the frequency is outside the bandwidth of any wafer probe capability

- Under this program, Andy Fung, together with Greg Boll of GGB, developed and the *very first* wafer probe measurements *up to 500 GHz*.
- We have used the probes to measure the 2007 circuits, and have found very high gain up to 500 GHz (~10 dB at 475 GHz with 40 GHz bandwidth)
- Cryogenic noise testing of these chips is beyond the current scope of this program, due to the need for developing a low loss waveguide package capable of being cooled.
- A new RTD Topic has been submitted (PI Samoska) "MMIC Low Noise Amplifier Modules up to 700 GHz– A World Record Enabling Technology" to package and test these amplifiers cryogenically. by fabricating low loss waveguide transitions in the MDL.



Progress in 10 years?



HAMSR Microwave Sounder on Global Hawk

Bjorn Lambrigtsen, Shannon Brown - JPL

Thermodynamic structure


- -T(z), q(z), L(z) clear & cloudy
- -Rain rate, IWP (experimental)
- -1 km V x 2 km H in 40-km swath
- -25 channels: 50, 118 and 183 GHz

New receiver technology

- 183 GHz receiver upgraded with LNA developed under NASA/ESTO/ACT
- Noise reduced by an order of magnitude
- Defines new state-of-the art



Chil and New HAMSH TAx 164 GHs clearer




Multiple platforms

- -ER-2 (CAMEX-4, TCSP)
- -DC-8 (NAMMA)
- Global Hawk (ready late 2009)

Convective structure

- Radar-like reflectivity
- 1 km vert.res/40 km swath
- Conv.intens., precip(z), ice(z)










Single-function modules




Systems are built from individual blocks, typically serving a single function.

Advantages: simple design, easy testing, cryogenic components can be limited to those requiring cooling, less subject to yield issues since rework is inexpensive. Disadvantages: complex integration, larger chains, more interconnects


Multi-function multi-chip packaging

Moderate integration:




Systems are still complicated to integrate but have fewer connections.

Components retain a large degree of RF testability. RF gain is typically limited, making design for stability easier



Multi-function multi-chip packaging


Highly integrated:



Large systems are easier to integrate.

Components retain minimal RF testability. RF gain is typically high.

Highly dependent upon device yield and repeatability.







Heterogeneous Integration Example

NORTHROP GRUMMAN


- Integrated RF front end module with antenna
 - PA (GaAs HEMT)
 - 3 bit phase shifter (GaAs HEMT)
 - Interconnections (ICICs)
 - Antenna




WLP bottom side WLP top side (antenna)




(Nearly) Idealized Lifecycle




QUIET W-Band Lifecycle



Cryogenic Testing-CIT Probe Station



Cryogenic Probe Station



Cryogenic Probe Station

